

Biomedical Image Processing: Processing images in GrayScale

Paul Vu
301169550
January 13th 2017

SFU

Determining FOV: Intuition




Figure 1: Selfie FOV illustration

Estimated Arm length $d = 360$ mm

Estimated θ for iPhone 5 front facing camera = 27° since the iPhone 5 lens has a 54° FOV as found on:

<https://www.boinx.com/chronicles/2013/3/22/field-of-view-fov-of-cameras-in-ios-devices/>

Determining FOV: Calculations




Figure 1: Selfie FOV illustration

$$\begin{aligned}\text{Height} &= (\text{Arm length } d) * \tan\theta \\ &= 360 * \tan(27)\end{aligned}$$

$$\begin{aligned}\text{FOV-y-axis} &= 2 * \text{Height} \\ &= 2 * 360 * \tan(27) \\ &= 366.85 \text{ mm}\end{aligned}$$

Thus, the Field of View in the vertical direction is 366.85 mm.

Determining Resolution: Intuition

- After importing the mugshot into MATLAB we know the image is 1280x960 samples
 - Total y-axis samples = $N_y = 1280$
 - Total x-axis samples = $N_x = 960$
- From part 1 we know our FOV-y-axis is 366.85mm therefore we can calculate the FOV-x-axis in mm by comparing the ratios in the x/y axis
- From there we can solve for Δx and Δy which represent the resolution in mm as depicted in lecture 2 page 2 : $\Delta x = \frac{FOV_x}{N_x}$ | | $\Delta y = \frac{FOV_y}{N_y}$

Determining Resolution: Calculations

$$\frac{y\text{-axis resolution in mm}}{x\text{-axis resolution in mm}} = \frac{366.85 \text{ mm}}{x\text{-axis resolution in mm}} = \frac{1280}{960}$$

$$\text{Therefore, x-axis resolution in mm} = \frac{960}{1280} * 366.85 \text{ mm} = 275.14 \text{ mm}$$

$$N_y = 1280 \quad N_x = 960$$

$$FOV_x = 275.14 \text{ mm}$$

$$FOV_y = 366.85 \text{ mm}$$

$$\text{Substituting } \Delta x = \frac{FOV_x}{N_x} \quad || \quad \Delta y = \frac{FOV_y}{N_y}$$

$$\Delta y = \frac{366.85}{1280} = 0.29 \text{ mm}$$

$$\Delta x = \frac{275.14}{960} = 0.29 \text{ mm}$$

Therefore we have a resolution of 0.29 mm in both the x and y sample axis.

Number of samples in x-y dimensions

From MATLAB, we can see that there are 1280 y-samples and 960 x-samples.

```
>> info = imfinfo('mugshot1.jpg')  
  
info =  
  
    struct with fields:  
  
        Filename: '/Users/luapvu/Desktop/ENSC 474/Assignments/Assi...'  
        FileModDate: '08-Jan-2017 15:20:52'  
        FileSize: 217890  
        Format: 'jpg'  
        FormatVersion: ''  
        Width: 1280  
        Height: 960  
        BitDepth: 24  
        ColorType: 'truecolor'  
        FormatSignature: ''  
        NumberOfSamples: 3
```

Figure 2: iminfo results of mugshot

Number of bits used per sample

Intuition:

Each sample contains an R-G-B component. Since each component is represented by 8 bits in MATLAB, each sample will have an 8 bit Red, 8 Bit Green and 8 Bit Blue component.

Calculation:

8-bit Red + 8-bit Green + 8-bit Blue = 24 bit RGB representation per sample

Therefore, each sample is represented by 24 bits.

Total bits required to store the image

Intuition:

There are 1280×960 samples of 24bits. There are 8 bits in 1 byte.

Calculations:

$$\frac{(1280 \times 960 \text{ samples}) \times \left(24 \frac{\text{bits}}{\text{sample}}\right)}{\left(8 \frac{\text{bits}}{\text{byte}}\right)} = 3,686,400 \text{ bytes}$$

Actual image size on disk

From the image properties, we can see that the JPEG image has been compressed to 217,890 bytes.




Figure 3: Mugshot image properties on MAC

Compression ratio

Calculation:

Number of bits on disk = 217, 890 bytes

Required total number of bits = 3,686,400 bytes

Compression ratio = $\frac{217,890 \text{ bytes}}{3,686,400 \text{ bytes}} = 0.0591 = \text{approximately } 16:1 \text{ compression ratio. We can see that}$
JPEG has significantly compressed the photo.

Assignment Results

To replicate these results please run `Assignment1_main.m` which is the main script.



Figure 4: From left to right, we have a mugshot in gray scale, smile shot in gray scale and the resulting difference image when the two images are subtracted with each other